

ASSP

ISO/IEC 15693 Compliant FRAM[®] Embedded High-speed RFID LSI FerVID family[™]

MB89R119

■ DESCRIPTION

The MB89R119 is an LSI device that has built-in high-speed FRAM and is used for vicinity-RFID.

■ FEATURES

- Memory capacity of 256 bytes FRAM (including 232 bytes of user area)
- 4-byte/block configuration, 64 blocks
- High-speed programming at 37.76 μ s per block (internal programming time)
- High-speed data transmission and reception at 26.48 Kbps
- Fast command supported (data transmission at 52.97 Kbps) (Transponder→Reader/Writer)
- Carrier frequency at 13.56 MHz
- Anti-collision function : 30 tags per second
- Endurance : 10^{10} writes to memory
- Data Retention : 10 years at +55 °C
- 64-bit UID
- FRAM memory data protection
- Anti-theft (EAS) command
- Kill command : to disable tag
- Compliance with ISO/IEC 15693 (partly not supported*)
- Compliance with ISO/IEC 18000-3 (Mode 1) (partly not supported*)


* : Refer to "■ NOTES ON USING".

FRAM is a registered trademark of Ramtron International Corporation.

FerVID family is a trademark of Fujitsu Limited.

MB89R119

■ BLOCK DIAGRAM



■ MEMORY MAP

This section describes the FRAM memory, which is the internal memory of the MB89R119.

• FRAM Configuration

The FRAM has 232 bytes for use as user area and 24 bytes for use as system area.

The FRAM memory areas consist of a total of 64 blocks (58 blocks of user area and 6 blocks of system area).

Each block can store 32 bits (4 bytes) of data.

The block is the unit used for the writing and reading of FRAM data. The memory map of the FRAM is shown below.

• FRAM configuration

Area	Block No.	Details	Data read	Data write
User area (232 bytes)	00 _H to 39 _H	User area	Yes	Yes
System area (24 bytes)	3A _H	RFU*	Yes	No
	3B _H	UID1 (1 to 32 bit)	Yes	No
	3C _H	UID2 (33 to 64 bit)	Yes	No
	3D _H	EAS, AFI, DSFID, IC Reference	Yes	Limited
	3E _H ,3F _H	Block security status	Yes	No

* : Reserved for future use

Blocks “00_H” to “39_H” are user area. The user area is defined as an area that can be accessed when the corresponding block address is specified. On the other hands, Blocks “3A_H” to “3F_H” are system area. The system area is defined as an area that can be accessed only with a specific command (request).

The system area consists of 6 blocks and contains UID, AFI, DSFID, EAS, IC reference and security status (can write or cannot write) data for individual block. UID, IC reference and RFU is fixed and cannot be updated. AFI, DSFID, and EAS bit are written at the factory, and can be updated and locked (disable to write) with commands. (Only EAS bit cannot be locked.)

As shown in above, “3B_H” and “3C_H” hold the UID, and “3E_H” and “3F_H” hold the security status information on individual user areas, AFI, and DSFID.

As shown in “• Structure of 3D_H”, “3D_H” contains EAS bit, AFI, DSFID and IC reference. As shown in the next following figure system areas, “3E_H” and “3F_H” contains block security status data.

• Structure of “3D_H”

MSB				LSB				
32	31	25	24	17	16	9	8	1
EAS Status		Internally used		IC Reference		DSFID		AFI

MB89R119

• Structure of “3E_H” and “3F_H”

		MSB				LSB	
		32	31	• • •	26	• • •	1
3E _H	Block security status (BBS) of user block 1F _H	• • •					BBS of 00 _H
3F _H	AFI Lock Status	DSFID Lock Status	RFU* (4 bits)	BBS of 39 _H	• • •	BBS of 20 _H	

* : Reserved for future use

The security status of the user area for 58 blocks is stored in the block security status bits in 2 system area blocks of “3E_H” and “3F_H”. A user area is unlocked when the corresponding block security status bit is “0”; it is locked (disable to write state) when the corresponding block security status bit is “1”. In the same way, the security status of AFI and DSFID are stored in “AFI Lock Status” and “DSFID Lock Status” respectively.

It is possible to read up to 64 blocks data by one command and to write up to 2 blocks data by one command.

EAS bit is a single bit, and it is used for setting EAS status.

■ DATA ELEMENT DEFINITION

1. Unique Identifier (UID)

The MB89R119 has a 64-bit unique identifier (UID) that complies with ISO/IEC 15693-3. The UID is used to distinguish a transponder from another transponder in the anti-collision algorithm described later.

The UID consists of the 3 items shown in the following.

- An 8-bit data whose value is always “E0_H” (bit 57 to bit 64)
- An 8-bit IC manufacturer’s code whose value is always “08_H”, which is defined by ISO/IEC 7816-6/AMI (bit 49 to bit 56)
- Unique 48-bit serial number assigned by Fujitsu (bit 1 to bit 48)

Among the unique 48-bit serial number assigned by Fujitsu, the 1 byte from bit 41 to bit 48 defines MB89R119 code whose value is “02_H”. And the 5 bytes from bit 1 to bit 40 define Chip Information.

• Structure of UID

MSB				LSB			
64	57	56	49	48	41	40	1
“E0 _H ”		IC manufacturer code “08 _H ”		“02 _H ”		Chip information	
Unique serial number assigned by Fujitsu							

2. Application Family Identifier (AFI)

The application family identifier (AFI) identifies the type of application set by the transponder.

The AFI can be written with a command. The AFI is 8-bit data and is stored in the system area of memory (FRAM).

The factory default setting of the AFI is "00H".

• Types of AFI

Application Family (b8-b5)	Application Sub-Family (b4-b1)	Application Use Field	Example/Note
"0"	"0"	All families and sub-families	No application preselection
X	"0"	All sub-families of family X	Wide applicative preselection
X	Y	Only the Yth sub-families of family X	
"0"	Y	All families of Yth sub-families	
"1"	"0", Y	Transport	Mass transit, bus, airline
"2"	"0", Y	Financial	IEP, banking, retail
"3"	"0", Y	Identification	Access control
"4"	"0", Y	Telecommunication	Public telephone, GSM
"5"	"0", Y	Medical	
"6"	"0", Y	Multimedia	Internet services
"7"	"0", Y	Gaming	
"8"	"0", Y	Data storage	Portable files
"9"	"0", Y	EAN-UCC system for application identifiers	Managed by ISO/IEC JTC1/SC31
"A"	"0", Y	ISO/IEC JTC1/SC31	Data identifiers as defined in ISO/IEC 15418
"B"	"0", Y	IATA	Managed by ISO/IEC JTC1/SC31
"C"	"0", Y	UPU	Managed by ISO/IEC JTC1/SC31
"D"	"0", Y	RFU*	Managed by ISO/IEC JTC1/SC31
"E"	"0", Y	RFU*	Managed by ISO/IEC JTC1/SC31
"F"	"0", Y	RFU*	Managed by ISO/IEC JTC1/SC31

* : Reserved for future use

Note : Both X value and Y value are "1" to "F".

In the status of the AFI_flag setting;

- If the AFI is not supported by the transponder, no response to all requests is returned.
- If the AFI is supported by the transponder, the response is returned only if the value is in accord with the AFI sent from a reader/writer.

3. Data Storage Format Identifier (DSFID)

The data storage format identifier (DSFID) indicates how data is structured in the transponder (LSI memory device). The DSFID can be programmed with a command.

The DSFID is 8-bit data and is stored in the system area of memory (FRAM). The factory default setting of the DSFID is "01H".


4. Cyclic Redundancy Check (CRC)

When a frame is received, reception of correct data--that is, the characters making up the frame is assumed only when the value of the cyclic redundancy check (CRC) code is valid. For error-checking purposes, a 2-byte CRC code value is inserted between data and the EOF signal.

The value of CRC code is required from all the data contained between the SOF and CRC field in each frame. Method of calculation is provided in ISO/IEC 13239 and the detail is defined in ISO/IEC 15693-3 and ISO/IEC 18000-3. The initial value of the CRC code provided in ISO/IEC 15693-3 is "FFFF_H".

The CRC code is transferred, beginning with the lowest-order bit in the lowest-order byte.

- CRC bit/byte transition order



5. Electronic Article Surveillance (EAS) status

EAS status is 1 bit data, which is stored in the system area of memory (FRAM) . The initial value is "1". EAS bit "1" means goods-monitoring status, and EAS bit "0" means that goods-monitoring status is cleared. EAS status can be written by Write EAS command and can be checked "3D_H" block (refer to "■ MEMORY MAP") by Read commands such as Read Signal Block command.

Together with Gate type reader/writer, EAS command can support anti-theft security functions.

MB89R119

■ ABSOLUTE MAXIMUM RATINGS

Parameter	Symbol	Ratings		Unit	Remarks
		Min	Max		
Maximum antenna input current	I _{max}	—	90	mA _{0-p}	
ESD voltage immunity	V _{ESD}	± 2	—	kV	Human body model
Storage temperature	T _{stg}	- 40	+ 85	°C	

WARNING: Semiconductor devices can be permanently damaged by application of stress (voltage, current, temperature, etc.) in excess of absolute maximum ratings. Do not exceed these ratings.

■ RECOMMENDED OPERATING CONDITIONS

Parameter	Symbol	Value			Unit	Remarks
		Min	Typ	Max		
Minimum antenna input voltage	V _{RF}	—	9.2	11.2	V _{p-p}	
Antenna input current	I _{RF}	—	—	30	mArms	
ASK modulation index (10%)	m	10	—	30	%	
ASK modulation index (100%)	m	95	—	100	%	
ASK pulse width (10%)	t ₁	6.0	—	9.44	μs	
	t ₂	3.0	—	t ₁	μs	
	t ₃	0	—	4.5	μs	
ASK pulse width (100%)	t ₁	6.0	—	9.44	μs	
	t ₂	2.1	—	t ₁	μs	
	t ₃	0	—	4.5	μs	
	t ₄	0	—	0.8	μs	
Input frequency	F _{in}	13.553	13.560	13.567	MHz	
Operating temperature	T _a	- 20	—	+ 85	°C	

WARNING: The recommended operating conditions are required in order to ensure the normal operation of the semiconductor device. All of the device's electrical characteristics are warranted when the device is operated within these ranges.

Always use semiconductor devices within their recommended operating condition ranges. Operation outside these ranges may adversely affect reliability and could result in device failure.

No warranty is made with respect to uses, operating conditions, or combinations not represented on the data sheet. Users considering application outside the listed conditions are advised to contact their FUJITSU representatives beforehand.

■ ELECTRICAL CHARACTERISTICS

DC characteristics

Parameter	Symbol	Value			Unit	Remarks
		Min	Typ	Max		
Internal power supply voltage	VDP3	3.0	3.3	3.6	V	
Load modulation resistance	R _{lsw}	—	1.0	—	kΩ	
Input capacitance*	C _{ant}	22.8	24.0	25.2	pF	Voltage between antennas = 2 V _{rms}
Internal power consumption	P _d	—	100	—	μW	


* : Values are controlled by process monitoring in the wafer.

■ FUNCTION DESCRIPTION


1. Communication from Reader/Writer to Transponder

- Modulation method : 10% ASK modulation and 100% ASK modulation are supported.
- Modulation rate (m): Modulation rate m is defined as $m = (a - b)/(a + b)$ with reference to the modulated waveform shown below. The values a and b indicate, respectively, the maximum and minimum amplitude of magnetic field transmitted from a reader/writer.

- Modulation of the carrier for 10% ASK



- Modulation of the carrier for 100% ASK




Maximum and minimum values of t_1 , t_2 and t_3 are specified in "■ RECOMMENDED OPERATION CONDITIONS". t_4 is $0.05(a-b)$ and the maximum value of t_1 and t_3 is $0.1(a-b)$.


- Data rate and bit coding : The MB89R119 supports only 1-out-of-4 mode for bit coding. (Not supports 1-out-of-256 mode.)
 - 1-out-of-4 mode : In 1-out-of-4 mode, 2-bit signals are coded in a period of 75.52 μs as shown in the following. When coding takes place, the data rate is 26.48 Kbps ($f_c/512$). Each signal is transmitted beginning with the lowest bit.

- Coding Method in 1-out-of-4 Mode


- "00_B" pulse position




- "01_B" pulse position (1 = LSB)



- "10_B" pulse position (0 = LSB)




- "11_B" pulse position (0 = LSB)



- Data frame : A data frame begins with a start-of-frame (SOF) signal and ends with an end-of-frame (EOF) signal. The MB89R119 is enabled to receive a frame from a reader/writer in 300 μs after the MB89R119 has sent a frame to the reader/writer. The MB89R119 is also enabled to receive a frame from a reader/writer within 1 ms after power has been supplied to the MB89R119.

- Waveforms of SOF and EOF signals of a frame sent from a reader/writer



MB89R119

2. Communication from Transponder to Reader/Writer

- Minimum load modulation amplitude (V_{lm}) : 10 mV (based on ISO/IEC 10373-7)
- Load modulation subcarrier frequency (f_s) : 423.75 kHz(f_c/32)
 The MB89R119 supports only a 1-subcarrier system.
 (Not supports 2-subcarrier system.)

- Data rate : The MB89R119 supports the following 2 data rate modes :
 - Low data rate
 - High data rate


One of the 2 data rate modes is specified by the Data_rate_flag (described later) sent from the reader/writer. In low data rate mode, the data rate is 6.62 Kbps (f_c/2048); in high data rate mode, it is 26.48 Kbps (f_c/512).

Also the Fast commands (Custom commands) supports the 2 data rate modes specified by the Data_rate_flag. In Low data rate mode, the data rate is 13.24 Kbps (f_c/1024) ; in high data rate mode, it is 52.97 Kbps (f_c/256)


- Bit coding : The Manchester coding is used for the bit coding. The following figure shows the signals modulated in high data rate mode when standard command is used, and the next following figure shows the same signals when fast command is used. In low data rate mode of both standard commands and fast commands, the number of pulses for subcarrier and data transfer time is 4 times as large as the number in high data rate mode.

- Signal waveforms by load modulation in high data rate mode (standard commands)

- Logic 0




- Logic 1




- Signal waveforms by load modulation in high data rate response mode (fast commands)

- Logic 0



- Logic 1



- Data frame : A data frame sent from a transponder starts with a start-of-frame (SOF) signal and ends with an end-of-frame (EOF) signal. The following figure shows the SOF and EOF signals sent in high data rate mode when standard command is used, and the next following figure shows the same signals when fast command is used.

In low data rate mode of both standard commands and fast commands, the number of pulses and data transfer time is 4 times as large as the number in high data rate mode, which is the same as explained in the figure below. A reader/writer that has sent a frame to a transponder must be enabled to receive a frame from the transponder within 300 μs after the reader/writer has completed sending of the frame.

- Waveforms of SOF and EOF signals of a frame sent from a transponder (standard commands)

- SOF




- EOF




- Waveforms of SOF and EOF signals of a frame sent from a transponder (fast commands)

- SOF



- EOF



3. FRAM Data Protection if Power Lost During Data Writing

If the power to nonvolatile memory is lost while data is being written to it, data may take on unexpected values, possibly adversely affecting system operation.

The MB89R119's FRAM is accessed (updated) in byte units.

The MB89R119 circle confirms that the level of power supply voltage is sufficient before data is written to each byte.

However, since write commands access more than one byte at once a power loss in the middle of write commands may result in a mixture of new written data and still remaining old data. As a result, confirm success of a write command with read command after each write command.

4. Requests/Responses

A request is sent from the reader/writer to the transponder. In reply to the request, the transponder sends a response to the reader/writer.

Each request, and each response, is transmitted in a single frame.

- Structure of requests and responses

A request consists of the following 5 fields :

- Flag
- Command code
- Parameter (required or optional depending on the command)
- Application data
- CRC

A response consists of the following 4 fields :

- Flag
- Parameter (required or option depending on the command)
- Application data
- CRC

Each byte is transferred, beginning with the lowest bit. When two or more bytes are transferred, transfer begins with the lowest one.

Set the RFU_flag always to "0".

5. Operating Modes

The MB89R119 has the following 2 operating modes :

Each mode specifies a different mechanism for how the transponder returns a response in reply to a request from the reader/writer :

- Addressed mode

The MB89R119 enters addressed mode when the Address_flag is set to "1".

In addressed mode, a request includes a UID (the Address_flag is set to "1" simultaneously), and only the transponder that matches the UID in the request returns a response. If no transponder that matches the UID exists, a response is not returned.


- Non-Addressed mode

The MB89R119 enters non-addressed mode when the Address_flag is set to "0".

In non-addressed mode, a request does not include a UID. The transponders that receive the request execute processing and return response in accordance with the command in the request.

6. Request Format

Figure shows a typical example of the request data format, and Table shows the definition of request flag bits.



- Setting of Bit 1 to Bit 4

Bit number	Flag name	1/0	State/Description
Bit 1	Sub-carrier_flag	0	One subcarrier selected
		1	Two subcarriers selected (not supported)
Bit 2	Data_rate_flag	0	Low data rate (6.62 Kbps) selected
		1	High data rate (26.48 Kbps) selected
Bit 3	Inventory_flag	0	Command other than Inventory command selected
		1	Inventory command selected
Bit 4	Protocol_Extension_flag	0	Protocol not extended
		1	Protocol extended (not supported)

Note : "Inventory_flag" of bit3 is determined whether "Inventory command" (select "1") or other command (select "0") is used.

MB89R119

- Setting of Bit 5 to Bit 8 (When Inventory command is selected [Inventory_flag = "1"])

Bit number	Flag name	1/0	State/Description
Bit 5	AFI_flag	0	AFI not set
		1	AFI set (response when it is in accord with AFI of the transponder)
Bit 6	Nb_slots_flag	0	16-slots (for one or more transponders)
		1	1-slot (for one transponder)
Bit 7	Option_flag	0	Command option not supported (for the command not supporting the Option_flag)
		1	Command option supported (not supported)
Bit 8	RFU*	0	Set to "0"
		1	—

* : Reserved for future use

- Setting of Bit 5 to Bit 8 (When the command other than Inventory command is selected [Inventory_flag = "0"])

Bit number	Flag name	1/0	State/Description
Bit 5	Select_flag	0	Command flag decided by the setting of bit 6 and later bits.
		1	Select mode (not supported)
Bit 6	Address_flag	0	Non addressed mode (UID not included in the command)
		1	Addressed mode (UID included in the command)
Bit 7	Option_flag	0	Command option not supported (for the command not supporting the Option_flag)
		1	Command option supported (for only Write, Lock commands)
Bit 8	RFU*	0	Set to "0"
		1	—

* : Reserved for future use


7. Response Format

Figure shows a typical example of the response data format, and table shows the definition of the response flag bits.

If the error flag is set to "1", an error code field is generated in the response. If the error flag is set to "0", this means no error, and If the error flag is set to "1", this means any error generation.

Error codes and their meaning are showed in Table.

- Structure of the response frame



• Response flag definitions

Bit number	Flag name	State	Description
Bit 1	Error_flag	0	Error not found
		1	Error found
Bit 2	RFU*	0	Set to "0"
Bit 3	RFU*	0	Set to "0"
Bit 4	Extension_flag	0	Set to "0"
Bit 5	RFU*	0	Set to "0"
Bit 6	RFU*	0	Set to "0"
Bit 7	RFU*	0	Set to "0"
Bit 8	RFU*	0	Set to "0"

* : Reserved for future use

• Error code definitions

Error code	Meaning
"01"	The specific command is not supported. Example: Command code error
"02"	Cannot recognize the command. Example: Format error
"03"	Specific options are not supported.
"10"	The specified block cannot be used (or was not found).
"11"	The specified block has already been locked and cannot be locked again.
"12"	The specified block has already been locked, and its contents cannot be changed.
"13"	The specified block could not be programmed normally (a write verify error occurred).
"14"	The specified block could not be locked normally (a lock verify error occurred).

8. Anti-Collision Algorithm

The MB89R119 executes an anti-collision sequence loop based on an algorithm that complies with ISO/IEC 15693-3.

The anti-collision algorithm is designed to examine the transponders located within reader/writer communication areas on the basis of UID.

The reader/writer issues an Inventory request (command) to transponders, and some transponders return responses while other transponders do not according to the algorithm explained in "10. Execution of Inventory Command by a Transponder".

9. REQUEST PARAMETER

• Request Parameter Settings

Set the reader/writer as follows before issuing the Inventory command.

- The Nb_slots_flag (bit6), which is a request flag, is set to the desired value :
 "0" : 16 slots (for plural transponders)
 "1" : 1 slot (for single transponder)
- A mask length and a mask value are added after the command code.
- The mask length indicates the significant bits of the mask value.
- The mask value is integer bytes of data, transmitted beginning with the lowest bit. If the mask length is not a multiple of 8 (bits), 0 is padded on the MSB side of the mask value so that the data is in units of bytes.

The following figure shows an example of the mask value with padding. Since the mask length is 12 bits, the mask value is padded with 4 bits on the MSB side so that the mask data is in units of bytes (2 bytes = 16 bits in this case).

If the AFI flag in the request flags is set in the format explained in "• Structure of the request frame of 6 Request Format", an AFI field is added to the format. The command ends with transmission of an EOF signal as described in "1. Communication from Reader/Writer to Transponder". Thereafter, processing in the first slot starts immediately. To proceed to the next slot, the reader/writer sends an EOF signal.

• Format of the Command

SOF	Flag	Command code	Mask length	Mask value	CRC	EOF
	8 bits	8 bits	8 bits	0 to 64 bits	16 bits	

• Example of the Mask Value with Padding

MSB	LSB
0000	0100 1100 1111
Pad	Mask value

10. Execution of Inventory Command by a Transponder


A transponder returns a response to the reader/writer when its UID is equal to the value that consists of the mask value and the number of slots. The mask value is sent in the Inventory command, and the number of slots is determined by the number of times the EOF signal is transmitted.

- Algorithm for execution of processing by a transponder

The following figure shows the algorithm for the execution of processing by a transponder when an Inventory command is received. The next figure shows the relationship between the UID and the mask value.

- Algorithm for Execution of Processing by a Transponder when Inventory Command

NbS	: Total number of slots (1 or 16)
SN	: Current slot number
LSB (value, n)	: The "n" least significant bits of value
&	: Concatenation operator
Slot_Frame	: SOF or EOF




- Comparison of the mask value and the number of slots with the UID

Inventory command includes the mask value and mask length.
The mask value is padded with "0" into the higher bit side so to make the byte-unit length (a multiple of 8 bits).

If Inventory command is received, the slot counter is reset to "0".

If EOF is received, the increment of the slot counter is started by the transponder.

The value is compared with the least significant bits of UID of the transponder.
If the value is in accord with the mask value, the response is returned by the transponder.



11. Anti-Collision Sequence

- Execution of anti-collision sequence


A typical anti-collision sequence that is applied when the number of slots is 16 is executed as follows :

- 1) The reader/writer sends an Inventory command. The Nb_slots_flag of the request flags is set to "0" to specify the number of slots.
- 2) In slot 0, transponder 1 transmits its response in the time $t1_a$ from the detection of the rising edge of the EOF. In this case no collision occurs and the UID of transponder is received and registered by the reader/writer.
- 3) The reader/writer sends an EOF signal to switch to the next slot in the time $t2_a$ after the response 1.
- 4) In slot 1, transponder 2 and transponder 3 transmits its response in the time $t1_a$ from the detection of the rising edge of the EOF. In this case, the reader/writer cannot recognize the UIDs of the two transponders because the collision occurs, and the reader/writer remembers that a collision was detected in slot 1.
- 5) The reader/writer sends an EOF signal to switch to the next slot in the time $t2_a$ after the responses.
- 6) In slot 2, no transponder transmits a response. The reader/writer does not detect any response, and sends an EOF signal to switch to the next slot in the time $t3_a$ from the detection of the rising edge of the EOF.
- 7) In slot 3, transponder 4 and transponder 5 transmits its response in the time $t1_a$ from the detection of the rising edge of the EOF, and another collision occurs.
- 8) The reader/writer sends a request (for example, a Read Single Block command, described later) to the transponder 1, which UID was already correctly received.
- 9) All transponders detect a SOF signal and exit the anti-collision sequence. In this case, since the request is addressed to transponder 1 (Address Mode), only transponder 1 transmits its response.
- 10) All transponders are ready to receive another request from the reader/writer. If the Inventory command is sent again, the anti-collision sequence starts from slot 0.

Note: $t1_a$, $t2_a$, $t3_a$ are specified in clause 12.

MB89R119

• Example of Anti-Collision Sequence




12. Timing definitions

- (1) Transponder waiting time before transmitting its response after reception of an EOF from the reader/writer : $t1_a$
- After detection of an EOF signal sent from the reader/writer, each transponder must wait for a certain time ($t1_a$) before sending a response to the reader/writer. $t1_a$ begins at the rising edge of the EOF pulse, and it is defined as following. The minimum value is $4320/fc$ (= 318.6 μs), the nominal value is $4352/fc$ (= 320.9 μs), and the maximum value is $4384/fc$ (=323.3 μs).
- If the transponder detects a carrier modulation for ASK 100% or 10% within the time $t1_a$, it shall reset its $t1_a$ timer and wait for further time $t1_a$ before starting to transmit its response to a reader/writer.
- MB89R119 defines the same waiting time $t1_a$ for Write commands as followings, although the maximum value is not defined in ISO/IEC 15693-3 and ISO/IEC 18000-3 mode1. The minimum value is $4320/fc$ (= 318.6 μs), the nominal value is $4352/fc$ (= 320.9 μs), and the maximum value is $4384/fc$ (= 323.3 μs). Timing conditions for Write command in which the option_flag is "1", has optional field are defined in the command descriptions.
- (2) Transponder modulation ignore time after reception of an EOF from the reader/writer : $tmit$
- After detection of an EOF signal sent from the reader/writer, MB89R119 shall ignore any received 10%, modulation during $tmit$. $tmit$ starts from the detection of the rising edge of the EOF, and the minimum value is defined as $4384/fc$ (=323.3 μs) + $tnrt$. $tnrt$ stands for the response time of MB89R119.
- (3) Reader/writer waiting time before sending a subsequent request : $t2_a$
- When the reader/writer has received a response from the transponder to a previous request other than Inventory and Quiet command, it shall wait a time $t2_a$ before sending a subsequent request. The minimum value of $t2_a$ is 309.2 μs . It is defined in ISO/IEC 15693-3 and ISO/IEC 18000-3 mode1.
- When the reader/writer has sent Stay Quiet command or Kill command, which causes no response from the transponder, or MB89R119 does not return any response, MB89R119 can receive a command in 309.2 μs from the detection of the rising edge of the EOF.
- (4) Reader/writer waiting time before sending a request (switching to the next slot) during an Inventory process : $t2inv$
- During Inventory process, the reader/writer sends an EOF to switch to the next slot. In this case, the waiting time is defined as follows depending on whether transponders return responses.
- Waiting time applied when the reader/writer has received one or more responses : $t2invwr$
It is defined in ISO/IEC 15693-3 and ISO/IEC 18000-3 mode1 that when the reader/writer has received one or more responses, the reader/writer must wait until responses from the transponders have been completed (that is, the reader/writer receives an EOF or $tnrt$ passes). After that, the reader/writer must wait as additional $t2_a$, and then send a 10% or 100% ASK modulated EOF to switch to the next slot.
 - Waiting time applied for when the reader/writer has not received any responses : $t3_a$
When the reader/writer has not received any responses from the transponders, the reader/writer must wait until $t3_a$ passes before sending an EOF signal. In this case, $t3_a$ starts from the rising edge of the last sent EOF. The minimum value of $t3_a$ is defined as shown in the following table.
 - (a) If the reader/writer sends a 10% modulated EOF,
the minimum value of $t3_a$ (ASK 10%) is ' $4384/fc$ (= 323.3 μs) + $tnrt$ ' as shown in "• Timing specification".
 - (b) If the reader/writer sends a 100% modulated EOF,
the minimum value of $t3_a$ (ASK 100%) is ' $4384/fc$ (= 323.3 μs) + $tsot$ ' as shown in "• Timing specification".
- $tnrt$: The nominal response time of transponder
 $tsot$: The time duration for transponder to transmit a SOF to the reader/writer

MB89R119

• t3_a for ASK10% and ASK100% signal



• Timing specification

	Min	Typ	Max
t1_a	$4320/fc = 318.6 \mu s$	$4352/fc = 320.9 \mu s$	$4384/fc = 323.3 \mu s$
tmit	$4384/fc(323.3 \mu s) + tnrt$	—	—
t2_a	$4192/fc = 309.2 \mu s$	—	—
t2invwr	$t2_a + tnrt$	—	—
t3_a (ASK10%)	$4384/fc(323.3 \mu s) + tnrt$	—	—
t3_a (ASK100%)	$4384/fc(323.3 \mu s) + tsof$	—	—
tnrt	—	Low data rate : $15708.16 \mu s$ High data rate : $3927.04 \mu s$ Fast Low data rate : $7854.08 \mu s$ Fast High data rate : $1963.52 \mu s$	—
tsof	—	Low data rate : $604.16 \mu s$ High data rate : $151.04 \mu s$ Fast Low data rate : $302.08 \mu s$ Fast High data rate : $75.52 \mu s$	—

■ COMMAND LIST

Mandatory and Optional commands defined by ISO/IEC 15693-3 are supported (Partly not supported*).

* : Refer to “■ NOTE ON USING •Comparison between ratings of ISO/IEC 15693 and specification of MB89R119”.

The following Custom commands are supported :

- EAS command designed to monitor and prevent the theft of goods
- Write EAS command to write data to the EAS bit
- Fast command to respond at double speed compared to standard commands
- Kill command to disable the function of tag

• Command list

Command code	Command name	Command Type	Details
“01H”	Inventory	Mandatory	Execute the anti-collision sequence and get UID.
“02H”	Stay Quiet	Mandatory	Enter the Quiet state
“20H”	Read Single Block	Optional	Read the requested 1 block data in the user area
“21H”	Write Single Block	Optional	Write the requested 1 block data in the user area
“22H”	Lock Block	Optional	Lock (disable to write) the requested 1 block in the user area
“23H”	Read Multiple Blocks	Optional	Read the requested up to 64 blocks data in the user area
“24H”	Write Multiple Blocks	Optional	Write the requested 1 or 2 blocks data in the user area
“26H”	Reset to Ready	Optional	Enter the ready (communication enabled) state
“27H”	Write AFI	Optional	Write AFI (Application Family Identifier) data into FRAM.
“28H”	Lock AFI	Optional	Lock AFI data (disable to write)
“29H”	Write DSFID	Optional	Write DSFID (Data Storage Format Identifier) data into FRAM
“2AH”	Lock DSFID	Optional	Lock DSFID (Data Storage Format Identifier) data (disable to write)
“2BH”	Get System Information	Optional	Read the system information value (UID, DSFID, AFI, number of bytes per block, number of blocks in user area, and IC information)
“A0H”	EAS	Custom	When EAS bit is “1”, reply response code 6 times.
“A1H”	Write EAS	Custom	Write EAS data (1 bit). Data “1” validates anti-theft/article surveillance, and data “0” invalidates them.
“A6H”	Kill	Custom	Disable the tag
“B1H”	Fast Inventory	Custom	Fast response Inventory command
“C3H”	Fast Read Multiple Blocks	Custom	Fast response Read Multiple Blocks command
“C4H”	Fast Write Multiple Blocks	Custom	Fast response Write Multiple Blocks command

■ COMMAND DESCRIPTION

1. Description of Mandatory Command

(1) Inventory command

- Description of command

The Inventory command executes the anti-collision sequence.

Even though an error is detected during execution of this command, a response indicating the error is not returned.

The Inventory_flag (bit3) must be set to "1".

When the AFI_flag (bit5) in the Inventory command frame is set as "1", the response is returned in the following cases.

- The AFI value of the transponder is in accord with the Optional AFI value.
- The 4 bits value MSB of the Optional AFI is "0H", and the 4 bits value LSB of the Optional AFI is in accord with the 4 bits value LSB of the transponder.
- The 4 bits value LSB of the Optional AFI is "0H", and the 4 bits value MSB of the Optional AFI is in accord with the 4 bits value MSB of the transponder.
- The Optional AFI value is "00H".

For example, if the AFI value of the transponder is "69H", the response is returned when the Optional AFI value is "69H", "60H", "09H" or "00H".

- Command

[Request from the reader/writer to the transponder]

SOF	Flag	Command (Inventory)	Optional AFI	Mask length	Mask value	CRC	EOF
	8 bits	8 bits ("01H")	8 bits	8 bits	0 to 64 bits	16 bits	

- Response

[Response from the transponder to the reader/writer]

SOF	Flag	DSFID	UID	CRC	EOF
	8 bits ("00H")	8 bits	64 bits	16 bits	

(2) Stay Quiet command

- Description of command

On receiving the Stay Quiet command, the transponder enters the quiet state. The transponder does not return any responses, including an error indication.

In the quiet state, the transponder does not execute any request for which the Inventory_flag (bit 3) is set and executes only a command for which the Address_flag (bit 6) is set.

The transponder exits the quiet state only in the following cases :

- The transponder enters the power-off state.
- The transponder receives the Reset to Ready command and enters the ready state.

- Command

[Request from the reader/writer to the transponder]

SOF	Flag	Command (Stay Quiet)	UID (necessary)	CRC	EOF
	8 bits	8 bits ("02H")	64 bits	16 bits	

- Response

[Response from the transponder to the reader/writer]

No response

2. Description of Optional Command

(1) Read Single Block command

- Description of command

On receiving the Read Single Block command, the transponder returns the data stored in the specified single-block to the reader/writer as a response.

- Command

[Request from the reader/writer to the transponder]

SOF	Flag	Command (Read Single Block)	UID (Addressed mode)	Number of blocks	CRC	EOF
	8 bits	8 bits ("20H")	64 bits	8 bits	16 bits	

- Response

[Response from the transponder to the reader/writer]

(a) When Error_flag set

SOF	Flag	Error code	CRC	EOF
	8 bits ("01H")	8 bits	16 bits	

(b) When Error_flag not set

SOF	Flag	Data	CRC	EOF
	8 bits ("00H")	32 bits	16 bits	

(2) Write Single Block command

- Description of command

On receiving the Write Single Block command, the transponder writes the single-block data included in the request to the specified block.

The transponder performs verification after writing and returns an error code if the writing has failed.

If the Option_flag (bit 7) is "0", the transponder shall return its response when it has completed the write operation starting after $\langle t_{1nom} + \text{a multiple of } 4096/f_c (302.1 \mu\text{s}) \rangle$ with total tolerance of $\pm 32/f_c (2.4 \mu\text{s})$ and latest within 20 ms. If it is "1", transponder shall wait for the reception of an EOF from the reader/writer and upon such reception still return its response. (However, if an EOF is not sent within 20 ms, the time-out occurs and the transponder can receive another command.)

Note : $t_{1nom} = 320.9 \mu\text{s}$ (typical)

- Command

[Request from the reader/writer to the transponder]

SOF	Flag	Command (Write Single Block)	UID (Addressed mode)	Number of blocks	Data	CRC	EOF
	8 bits	8 bits ("21H")	64 bits	8 bits	32 bits	16 bits	

- Response

[Response from the transponder to the reader/writer]

(a) When Error_flag set

SOF	Flag	Error code	CRC	EOF
	8 bits ("01H")	8 bits	16 bits	

MB89R119

(b) When Error_flag not set

SOF	Flag	CRC	EOF
	8 bits ("00H")	16 bits	

(3) Lock Block command

- Description of command

On receiving the Lock Block command, the transponder locks the data stored in one specified single-block. The transponder performs verification after writing and returns an error code if the writing has failed.

If the Option_flag (bit 7) is "0", the transponder shall return its response when it has completed the lock operation starting after $\langle t1_{nom} + \text{a multiple of } 4096/f_c (302.1 \mu s) \rangle$ with total tolerance of $\pm 32/f_c (2.4 \mu s)$ and latest within 20 ms. If it is "1", transponder shall wait for the reception of an EOF from the reader/writer and upon such reception still return its response. (However, if an EOF is not sent within 20 ms, the time-out occurs and the transponder can receive another command.)

Once the Lock Block command has been received, data in the locked block cannot be changed by the Write Single(Multiple) Block command.

- Command

[Request from the reader/writer to the transponder]

SOF	Flag	Command (Lock Block)	UID (Addressed mode)	Number of blocks	CRC	EOF
	8 bits	8 bits ("22H")	64 bits	8 bits	16 bits	

- Response

[Response from the transponder to the reader/writer]

(a) When Error_flag set

SOF	Flag	Error code	CRC	EOF
	8 bits ("01H")	8 bits	16 bits	

(b) When Error_flag not set

SOF	Flag	CRC	EOF
	8 bits ("00H")	16 bits	

(4) Read Multiple Blocks Command

- Description of command

On receiving the Read Multiple Blocks command, the transponder returns the data stored in the specified successive blocks to the reader/writer as a response.

Up to 64 blocks of data can be read for one request.

The value of the "number of blocks" field specified in the request is the expected number of blocks minus 1. Setting the number of blocks to "06H" makes a request to read 7 blocks. Setting the number of blocks to "00H" makes a request to read 1 block (the request having the same effect as the Read Single Block command). The maximum number of blocks to be set is "3FH".

Note : For execution in the addressed mode, the Read Multiple Blocks command must be run without shutting off the RF power supply after obtaining the UID, for example, using the Inventory command. No response may be expected when RF power supply is not stable.

- Command

[Request from the reader/writer to the transponder]

SOF	Flag	Command (Read Multiple Blocks)	UID (Addressed mode)	First block number	Number of blocks	CRC	EOF
	8 bits	8 bits ("23H")	64 bits	8 bits	8 bits	16 bits	

- Response

[Response from the transponder to the reader/writer]

(a) When Error_flag set

SOF	Flag	Error code	CRC	EOF
	8 bits ("01H")	8 bits	16 bits	

(b) When Error_flag not set

SOF	Flag	Data	CRC	EOF
	8 bits ("00H")	32xn bits *	16 bits	

*: n is the number of blocks to be responded.

(5) Write Multiple Blocks Command

- Description of command

On receiving the Write Multiple Blocks command, the transponder writes the successive multiple-block data included in the request to the specified blocks.

Up to 2 blocks of data can be written for one request.

The transponder performs verification after writing and returns an error code if the writing has failed. The number of blocks specified in the Write Multiple Blocks command is similar to the number of blocks specified in the Read Multiple Blocks command. The value of the number of blocks field specified in the Write Multiple Blocks command is obtained by subtracting 1 from the number of the expected blocks to be written.

Setting the number of blocks to "01H" makes a request to write 2 blocks. Setting the number of blocks to "00H" makes a request to write 1 block (the request having the same effect as the Write Single Block command). If at least one of the blocks specified by the command is locked, the transponder does not write any data and, instead, returns an error code.

If the Option_flag (bit 7) is "0", the transponder shall return its response when it has completed the write operation starting after $\langle t1_{nom} + a \text{ multiple of } 4096/f_c (302.1 \mu s) \rangle$ with total tolerance of $\pm 32/f_c (2.4 \mu s)$ and latest within 20 ms. If it is "1", transponder shall wait for the reception of an EOF from the reader/writer and upon such reception still return its response. (However, if an EOF is not sent within 20 ms, the time-out occurs and the transponder can receive another command.)

- Command

[Request from the reader/writer to the transponder]

SOF	Flag	Command (Write Multiple Blocks)	UID (Addressed mode)	First block number	Number of blocks	Data	CRC	EOF
	8 bits	8 bits ("24H")	64 bits	8 bits	8 bits	32 or 64 bits	16 bits	

- Response

[Response from the transponder to the reader/writer]

(a) When Error_flag set

SOF	Flag	Error code	CRC	EOF
	8 bits ("01H")	8 bits	16 bits	

MB89R119

(b) When Error_flag not set

SOF	Flag	CRC	EOF
	8 bits ("00H")	16 bits	

(6) Reset to Ready command

- Description of command

On receiving the Reset to Ready command, the transponder enters the ready state.

- Command

[Request from the reader/writer to the transponder]

SOF	Flag	Command (Reset to Ready)	UID (Addressed mode)	CRC	EOF
	8 bits	8 bits ("26H")	64 bits	16 bits	

- Response

[Response from the transponder to the reader/writer]

(a) When Error_flag set

SOF	Flag	Error code	CRC	EOF
	8 bits ("01H")	8 bits	16 bits	

(b) When Error_flag not set

SOF	Flag	CRC	EOF
	8 bits ("00H")	16 bits	

(7) Write AFI command

- Description of command

On receiving the Write AFI command, the transponder writes the specified AFI data to FRAM.

The transponder performs verification after writing and returns an error code if the writing has failed.

If the Option_flag (bit 7) is "0", the transponder shall return its response when it has completed the write operation starting after $\langle t_{1\text{nom}} + \text{a multiple of } 4096/f_c (302.1 \mu\text{s}) \rangle$ with total tolerance of $\pm 32/f_c (2.4 \mu\text{s})$ and latest within 20 ms. If it is "1", transponder shall wait for the reception of an EOF from the reader/writer and upon such reception still return its response. (However, if an EOF is not sent within 20 ms, the time-out occurs and the transponder can receive another command.)

- Command

[Request from the reader/writer to the transponder]

SOF	Flag	Command (Write AFI)	UID (Addressed mode)	AFI	CRC	EOF
	8 bits	8 bits ("27H")	64 bits	8 bits	16 bits	

- Response

[Response from the transponder to the reader/writer]

(a) When Error_flag set

SOF	Flag	Error code	CRC	EOF
	8 bits ("01H")	8 bits	16 bits	

(b) When Error_flag not set

SOF	Flag	CRC	EOF
	8 bits ("00H")	16 bits	

(8) Lock AFI command

- Description of command

On receiving the Lock AFI command, the transponder locks (write disable) the stored AFI data.

The transponder performs verification after writing and returns an error code if the writing has failed.

If the Option_flag (bit 7) is "0", the transponder shall return its response when it has completed the lock operation starting after $\langle t1_{nom} + \text{a multiple of } 4096/fc (302.1 \mu s) \rangle$ with total tolerance of $-32/fc$ to $+32/fc$ (2.4 μs) and latest within 20 ms. If it is "1", transponder shall wait for the reception of an EOF from the reader/writer and upon such reception still return its response. (However, if an EOF is not sent within 20 ms, the time-out occurs and the transponder can receive another command.)

Once the Lock AFI command has been received, the AFI data cannot be changed by the Write AFI command.

- Command

[Request from the reader/writer to the transponder]

SOF	Flag	Command (Lock AFI)	UID (Addressed mode)	CRC	EOF
	8 bits	8 bits ("28H")	64 bits	16 bits	

- Response

[Response from the transponder to the reader/writer]

(a) When Error_flag set

SOF	Flag	Error code	CRC	EOF
	8 bits ("01H")	8 bits	16 bits	

(b) When Error_flag not set

SOF	Flag	CRC	EOF
	8 bits ("00H")	16 bits	

(9) Write DSFID command

- Description of command

On receiving the Write DSFID command, the transponder writes the specified DSFID data to FRAM.

The transponder performs verification after writing and returns an error code if the writing has failed.

If the Option_flag (bit 7) is "0", the transponder shall return its response when it has completed the write operation starting after $\langle t1_{nom} + \text{a multiple of } 4096/fc (302.1 \mu s) \rangle$ with total tolerance of $\pm 32/fc$ (2.4 μs) and latest within 20 ms. If it is "1", transponder shall wait for the reception of an EOF from the reader/writer and upon such reception still return its response. (However, if an EOF is not sent within 20 ms, the time-out occurs and the transponder can receive another command.)

MB89R119

- Command

[Request from the reader/writer to the transponder]

SOF	Flag	Command (Write DSFID)	UID (Addressed mode)	DSFID	CRC	EOF
	8 bits	8 bits ("29H")	64 bits	8 bits	16 bits	

- Response

[Response from the transponder to the reader/writer]

(a) When Error_flag set

SOF	Flag	Error code	CRC	EOF
	8 bits ("01H")	8 bits	16 bits	

(b) When Error_flag not set

SOF	Flag	CRC	EOF
	8 bits ("00H")	16 bits	

(10) Lock DSFID command

- Description of command

On receiving the Lock DSFID command, the transponder locks (write disable) the stored DSFID data.

The transponder performs verification after writing and returns an error code if the writing has failed.

If the Option_flag (bit 7) is "0", the transponder shall return its response when it has completed the lock operation starting after $\langle t1_{nom} + a \text{ multiple of } 4096/f_c (302.1 \mu s) \rangle$ with total tolerance of $\pm 32/f_c (2.4 \mu s)$ and latest within 20 ms. If it is "1", transponder shall wait for the reception of an EOF from the reader/writer and upon such reception still return its response. (However, if an EOF is not sent within 20 ms, the time-out occurs and the transponder can receive another command.)

Once the Lock DSFID command has been received, the DSFID data cannot be changed by the Write DSFID command.

- Command

[Request from the reader/writer to the transponder]

SOF	Flag	Command (Lock DSFID)	UID (Addressed mode)	CRC	EOF
	8 bits	8 bits ("2AH")	64 bits	16 bits	

- Response

[Response from the transponder to the reader/writer]

(a) When Error_flag set

SOF	Flag	Error code	CRC	EOF
	8 bits ("01H")	8 bits	16 bits	

(b) When Error_flag not set

SOF	Flag	CRC	EOF
	8 bits ("00H")	16 bits	

(11) Get System Information command

- Description of command

On receiving the Get System Information command, the transponder returns the chip information of UID, AFI, DSFID, and so on to the reader/writer as a response.

- Command

[Request from the reader/writer to the transponder]

SOF	Flag	Command (Get System Info)	UID (Addressed mode)	CRC	EOF
	8 bits	8 bits ("2BH")	64 bits	16 bits	

- Response

[Response from the transponder to the reader/writer]

(a) When Error_flag set

SOF	Flag	Error code	CRC	EOF
	8 bits ("01H")	8 bits	16 bits	

(b) When Error_flag not set

SOF	Flag	Information flag	UID	DSFID	AFI	Memory size	IC reference	CRC	EOF
	8 bits ("00H")	8 bits	64 bits	8 bits	8 bits	16 bits	8 bits	16 bits	

The following table shows the definitions of the Information flag. The following figure shows the memory size information included in the response of the System Information. The block size shown in the figure indicates the value that is 1 byte less than the actual block size. Similarly, the number of blocks shown in the figure indicates the value that is 1 block less than the actual number of blocks.

- Definition of information flag

Bit No.	Flag name	State	Description
Bit 1	DSFID	0	DSFID is not supported or does not exist.
		1	DSFID is supported or exists.
Bit 2	AFI	0	AFI is not supported or does not exist.
		1	AFI is supported or exists.
Bit 3	Memory size	0	Memory size information is not supported or does not exist.
		1	Memory size information is supported or exists.
Bit 4	IC reference	0	IC reference information is not supported or does not exist.
		1	IC reference information is supported or exists.
Bit 5	RFU*	—	Set to "0"
Bit 6	RFU*	—	
Bit 7	RFU*	—	
Bit 8	RFU*	—	

* : Reserved for future use

Note : For MB89R119 set "1" for bit1 to bit4 and set "0" for bit5 to bit8.

MB89R119

- Memory size information about a transponder

MSB			LSB		
16	14	13	9	8	1
RFU*		Size of blocks (Number of bytes in 1 block)		Number of blocks	

* : Reserved for future use

Note : The memory size of the MB89R119 which is consisted of 58 blocks (4 bytes per block) in the user area is hexadecimal "0339H".

3. Custom Command

The IC manufacturing code is required to use a Custom command. The IC manufacturing code for the MB89R119 is "08_H".

(1) EAS command

- Description of command

On EAS command reception, the transponder returns the response code repeated 6 times after the specified flag ("00_H") if the EAS bit is "1" or returns no response if the EAS bit is "0". The EAS command can be executed only when the transponder is in the Ready state.

For the response code values, please inquire separately.

- Command

[Request from the reader/writer to the transponder]

SOF	Flag	Command (EAS)	IC manufacturer code (necessary)	CRC	EOF
	8 bits	8 bits ("A0 _H ")	8 bits("08 _H ")	16 bits	

- Response

[Response from the transponder to the reader/writer]

SOF	Flag	Response code	CRC	EOF
	8 bits ("00 _H ")	48 bits (6 times repeat of 8 bits data)	16 bits	

(2) Write EAS command

- Description of command

On write EAS command reception, the transponder writes the EAS bit to the FRAM.

The transponder performs verification after writing and returns an error code if the writing has failed.

The EAS bit must be set to "00_H" to cancel anti-theft or goods-monitoring mode. The bit must be set to "01_H" to set up the goods-monitoring mode.

If the Option_flag (bit 7) is "0", the transponder shall return its response when it has completed the write operation starting after $\langle t_{1nom} + \text{a multiple of } 4096/f_c (302.1 \mu\text{s}) \rangle$ with total tolerance of $-32/f_c$ to $+32/f_c (2.4 \mu\text{s})$ and latest within 20 ms. If it is "1", transponder shall wait for the reception of an EOF from the reader/writer and upon such reception still return its response. (However, if an EOF is not sent within 20 ms, the time-out error occurs and the transponder can receive another command.)

- Command

[Request from the reader/writer to the transponder]

SOF	Flag	Command (Write EAS)	IC manufacturer code (necessary)	UID (Addressed mode)	Data	CRC	EOF
	8 bits	8 bits ("A1 _H ")	8 bits ("08 _H ")	64 bits	8 bits ("00 _H " or "01 _H ")	16 bits	

- Response

[Response from the transponder to the reader/writer]

(a) When Error_flag set

SOF	Flag	Error code	CRC	EOF
	8 bits ("01 _H ")	8 bits	16 bits	

MB89R119

(b) When Error_flag not set

SOF	Flag	Data	CRC	EOF
	8 bits ("00H")	16 bits	16 bits	

(3) Kill Command

- Description of command

On the receiving the Kill command, the transponder is disabled and enters the Dead state. Even if the transponder is moved in the magnetic field (power-on state) again after being removed out of the magnetic field (power-off state), the transponder stays in the Dead state and never respond to any commands from the reader/writer.

- Command

[Request from the reader/writer to the transponder]

SOF	Flag	Command(Kill)	IC Mfg code (necessary)	UID (necessary)	CRC	EOF
	8 bits	8 bits ("A6H")	8 bits ("08H")	64 bits	16 bits	

- Response

[Response from the transponder to the reader/writer]

(a) When Error_flag set

SOF	Flag	Error code	CRC	EOF
	8 bits	8 bits	16 bits	

(b) When Error_flag not set

No response

WARNING: The transponder received Kill command is disabled and cannot be used again.

(4)Fast Inventory Command

- Description of command

The Fast Inventory command is the same as the Inventory Command that executes the anti-collision sequence. The datarate in the response is twice as defined in ISO/IEC 15693-3.

Even though an error is detected during execution of this command, a response indicating the error is not returned.

The Inventory_flag (bit3) must be set to "1".

When the AFI_flag (bit5) in the Inventory command frame is set as "1", the response is returned in the following cases.

- The AFI value of the transponder is in accord with the Optional AFI value.
- The 4 bits value MSB of the Optional AFI is "0H", and the 4 bits value LSB of the Optional AFI is in accord with the 4 bits value LSB of the transponder.
- The 4 bits value LSB of the Optional AFI is "0H", and the 4 bits value MSB of the Optional AFI is in accord with the 4 bits value MSB of the transponder.
- The Optional AFI value is "00H".

For example, if the AFI value of the transponder is "69H", the response is returned when the Optional AFI value is "69H", "60H", "09H" or "00H".

- Command

[Request from the reader/writer to the transponder]

SOF	Flag	Command (Fast Inventory)	IC manufacturer code (necessary)	Optional AFI	Mask length	Mask value	CRC	EOF
	8 bits	8 bits ("B1H")	8 bits ("08H")	8 bits	8 bits	0 to 64 bits	16 bits	

- Response

[Response from the transponder to the reader/writer]

SOF	Flag	DSFID	UID	CRC	EOF
	8 bits ("00H")	8 bits	64 bits	16 bits	

(5) Fast Read Multiple Blocks Command

- Description of command

The Fast Read Multiple Blocks command is the same as the Read Multiple Blocks Command that reads the specified successive blocks. The datarate in the response is twice as defined in ISO/IEC 15693.

Up to 64 blocks of data can be read for one request.

If the Option_flag (bit 7) is "1", the transponder adds block security status information in the response. If the Option_flag (bit 7) is "0", the transponder returns only the data in the specified blocks to the reader/writer.

The value of the "number of blocks" field specified in the request is the expected number of blocks minus 1. Setting the number of blocks to "06H" makes a request to read 7 blocks. Setting the number of blocks to "00H" makes a request to read 1 block (the request having the same effect as the Fast Read Single Block command). The maximum number of blocks to be set is "3FH".

Note : For execution in the addressed mode, the Fast Read Multiple Blocks command must be run without shutting off the RF power supply after obtaining the UID, for example, using the Inventory command. No response may be expected when RF power supply is not stable.

- Command

[Request from the reader/writer to the transponder]

SOF	Flag	Command (Fast Read Multiple Blocks)	IC manufacturer code (necessary)	UID (Addressed mode)	First block number	Number of blocks	CRC	EOF
	8 bits	8 bits ("C3H")	8 bits ("08H")	64 bits	8 bits	8 bits	16 bits	

- Response

[Response from the transponder to the reader/writer]

(a) When Error_flag set

SOF	Flag	Error code	CRC	EOF
	8 bits ("01H")	8 bits	16 bits	

(b) When Error_flag not set

SOF	Flag	Data	CRC	EOF
	8 bits ("00H")	32xn bits *	16 bits	

*: n is the number of blocks to be responded.

MB89R119

(6)Fast Write Multiple Blocks Command

- Description of command

The Fast Write Multiple Blocks command is the same as the Write Multiple Blocks Command, that writes the successive multiple-block data. The datarate in the response is twice as defined in ISO/IEC 15693.

Up to 2 blocks of data can be written for one request.

The transponder performs verification after writing and returns an error code if the writing has failed. The number of blocks specified in the Fast Write Multiple Blocks command is similar to the number of blocks specified in the Read Multiple Blocks command. The value of the number of blocks field specified in the Fast Write Multiple Blocks command is obtained by subtracting 1 from the number of the expected blocks to be written.

Setting the number of blocks to “01_H” makes a request to write 2 blocks. Setting the number of blocks to “00_H” makes a request to write 1 block (the request having the same effect as the Fast Write Single Block command). If at least one of the blocks specified for data writing is locked, the transponder does not write any data and, instead, returns an error code.

If the Option_flag (bit 7) is “0”, the transponder shall return its response when it has completed the write operation starting after $\langle t_{1nom} + \text{a multiple of } 4096/f_c (302.1 \mu\text{s}) \rangle$ with total tolerance of $- 32/f_c$ to $+ 32/f_c (2.4 \mu\text{s})$ and latest within 20 ms. If it is “1”, transponder shall wait for the reception of an EOF from the reader/writer and upon such reception still returns its response. (However, if an EOF is not sent within 20 ms, the time-out occurs and the transponder can receive another command.)

- Command

[Request from the reader/writer to the transponder]

SOF	Flag	Command (Fast Write Multiple Blocks)	IC manufacturer code	UID (Addressed mode)	First block number	Number of blocks	Data	CRC	EOF
	8 bits	8 bits (“C4 _H ”)	8 bits (“08 _H ”)	64 bits	8 bits	8 bits	32 or 64 bits	16 bits	

- Response

[Response from the transponder to the reader/writer]

(a) When Error_flag set

SOF	Flag	Error code	CRC	EOF
	8 bits (“01 _H ”)	8 bits	16 bits	

(b) When Error_flag not set

SOF	Flag	CRC	EOF
	8 bits (“00 _H ”)	16 bits	

4. Command Execution Time

(1) Write Multiple Blocks Command Execution Time

The minimum time (processing in the address mode) required to complete data writing to all user areas (232 bytes) of the FRAM and verification with the Write Multiple Blocks command is estimated to be 302 ms.

(2) Read Multiple Blocks Command Execution Time

The minimum time (processing in the address mode) required to complete data reading for all user areas (232 bytes) of the FRAM with the Read Multiple Blocks command is estimated to be 76 ms.

In addition, with the Fast Read Multiple Blocks command is estimated to be 41 ms.

MB89R119


■ STATE TRANSITION DIAGRAM

• Definition of states

Each state of MB89R119 is defined as follows.

- Power-Off the state : IF the power-off state, a transponder can not fulfill the function so that the voltage from a reader/writer is underpowered.
- Ready state : In the ready state, the MB89R119 can execute all commands from a reader/writer
- Quiet state : In the quiet state, the MB89R119 can execute the command from a reader/writer in which the Inventory_flag is not set and the Address_flag is set.
- Dead state : In the dead state, the MB89R119 can not execute any command from a reader/writer. As shown in the figure below, the MB89R119 moves from one state to another according to the status of power and by a command.

• State transition diagram



■ NOTES ON USING

- Notes on the radio interface

- It is the user's responsibility to reduce the effects of the electromagnetic waves produced by the reader/writer.
- The user must optimize the shapes of the antenna coils for transponder and reader/writer so that they match the transmission distance and installation space required for the user's application.
- If the user intends to access multiple transponders from a reader/writer, the interference between transponders or between the reader/writer and a transponder may degrade communication performance (transmission distance and communication time) . Therefore, a user who intends to design a system using multiple transponders should consider this point.

- FRAM reliability

Up to 10^{10} writes to the FRAM memory and 10 years of data retention at + 55 °C are guaranteed. For the data retention characteristics at + 150 °C or higher, see “■ SHIPPING METHOD AND RECOMMENDED ASSEMBLY CONDITIONS”.

- Difference between rating of ISO/IEC 15693 and MB89R119 implementation.

The table comparing rating of ISO/IEC 15693 to method of MB89R119 is shown in following.
Note that the MB89R119 implementation does not support following ratings.

- 1 out of 256 mode data coding
- 2-subcarrier


MB89R119

- Comparison between ratings of ISO/IEC 15693 and specification of MB89R119

Parameter	Details	ISO/IEC 15693 method	MB89R119 method
Communication method	10% ASK modulation method	Correspondence	Correspondence
	100% ASK modulation method	Correspondence	Correspondence
Range of modulation rate	(At using of 10% ASK)	10% to 30%	10% to 30%
Data coding	1 out of 256	Correspondence	Not correspondence
	1 out of 4	Correspondence	Correspondence
Subcarrier	1-subcarrier	Correspondence	Correspondence
	2-subcarrier	Correspondence	Not correspondence
Mandatory command	Inventory command	Correspondence	Correspondence
	Stay Quiet command	Correspondence	Correspondence
Optional command	Read Single Block command	Correspondence	Correspondence
	Write Single Block command	Correspondence	Correspondence
	Lock Block command	Correspondence	Correspondence
	Read Multiple Blocks command	Correspondence	Correspondence uppermost 64 blocks
	Write Multiple Blocks command	Correspondence	Correspondence uppermost 2 blocks
	Select command	Correspondence	Not correspondence
	Reset to ready command	Correspondence	Correspondence
	Write AFI command	Correspondence	Correspondence
	Lock AFI command	Correspondence	Correspondence
	Write DSFID command	Correspondence	Correspondence
	Lock DSFID command	Correspondence	Correspondence
	Get System Information command	Correspondence	Correspondence
	Get Multiple block security status command	Correspondence	Not correspondence

■ SHIPPING METHOD AND RECOMMENDED ASSEMBLY CONDITIONS

- Shipping Method for the MB89R119 : Please inquire separately for the method used to ship the MB89R119.
- The MB89R119 is recommended to be mounted in the following condition to maintain the data retention characteristics of the FRAM memory when the chip is mounted.



FUJITSU LIMITED

All Rights Reserved.

The contents of this document are subject to change without notice. Customers are advised to consult with FUJITSU sales representatives before ordering.

The information, such as descriptions of function and application circuit examples, in this document are presented solely for the purpose of reference to show examples of operations and uses of Fujitsu semiconductor device; Fujitsu does not warrant proper operation of the device with respect to use based on such information. When you develop equipment incorporating the device based on such information, you must assume any responsibility arising out of such use of the information. Fujitsu assumes no liability for any damages whatsoever arising out of the use of the information.

Any information in this document, including descriptions of function and schematic diagrams, shall not be construed as license of the use or exercise of any intellectual property right, such as patent right or copyright, or any other right of Fujitsu or any third party or does Fujitsu warrant non-infringement of any third-party's intellectual property right or other right by using such information. Fujitsu assumes no liability for any infringement of the intellectual property rights or other rights of third parties which would result from the use of information contained herein.

The products described in this document are designed, developed and manufactured as contemplated for general use, including without limitation, ordinary industrial use, general office use, personal use, and household use, but are not designed, developed and manufactured as contemplated (1) for use accompanying fatal risks or dangers that, unless extremely high safety is secured, could have a serious effect to the public, and could lead directly to death, personal injury, severe physical damage or other loss (i.e., nuclear reaction control in nuclear facility, aircraft flight control, air traffic control, mass transport control, medical life support system, missile launch control in weapon system), or (2) for use requiring extremely high reliability (i.e., submersible repeater and artificial satellite).

Please note that Fujitsu will not be liable against you and/or any third party for any claims or damages arising in connection with above-mentioned uses of the products.

Any semiconductor devices have an inherent chance of failure. You must protect against injury, damage or loss from such failures by incorporating safety design measures into your facility and equipment such as redundancy, fire protection, and prevention of over-current levels and other abnormal operating conditions.

If any products described in this document represent goods or technologies subject to certain restrictions on export under the Foreign Exchange and Foreign Trade Law of Japan, the prior authorization by Japanese government will be required for export of those products from Japan.