





Silicon PIN Diode

- High voltage current controlled
RF resistor for RF attenuator and switches
- Frequency range above 1 MHz
- Low resistance and short carrier lifetime
- For frequencies up to 3 GHz


BAR 64-04W

BAR 64-05W

BAR 64-06W


Type	Marking	Pin Configuration			Package
BAR 64-04W	PPs	1 = A1	2 = C2	3=C1/A2	SOT-323
BAR 64-05W	PRs	1 = A1	2 = C2	3 = C1/2	SOT-323
BAR 64-06W	PSs	1 = C1	2 = C2	3 = A1/2	SOT-323

Maximum Ratings

Parameter	Symbol	Value	Unit
Diode reverse voltage	V_R	150	V
Forward current	I_F	100	mA
Total power dissipation, $T_S \leq 115^\circ\text{C}$	P_{tot}	250	mW
Junction temperature	T_j	150	$^\circ\text{C}$
Operating temperature range	T_{op}	-55 ... 150	
Storage temperature	T_{stg}	-55 ... 150	

Thermal Resistance

Junction - ambient 1)	R_{thJA}	≤ 300	K/W
Junction - soldering point	R_{thJS}	≤ 140	


1) Package mounted on alumina 15mm x 16.7mm x 0.7mm

Electrical Characteristics at $T_A = 25^\circ\text{C}$, unless otherwise specified.


Parameter	Symbol	Values			Unit
		min.	typ.	max.	
DC characteristics					
Breakdown voltage $I_{(BR)} = 5 \mu\text{A}$	$V_{(\text{BR})}$	150	-	-	V
Reverse current $V_R = 20 \text{ V}$	I_R	-	-	50	nA
Forward voltage $I_F = 50 \text{ mA}$	V_F	-	-	1.1	V
AC characteristics					
Diode capacitance $V_R = 20 \text{ V}, f = 1 \text{ MHz}$	C_T	-	0.23	0.35	pF
Forward resistance $I_F = 1 \text{ mA}, f = 100 \text{ MHz}$	r_f	-	12.5	20	Ω
$I_F = 10 \text{ mA}, f = 100 \text{ MHz}$		-	2.1	2.8	
$I_F = 100 \text{ mA}, f = 100 \text{ MHz}$		-	0.85	1.35	
Charge carrier life time $I_F = 10 \text{ mA}, I_R = 6 \text{ mA}, I_R = 3 \text{ mA}$	τ_{rr}	-	1.55	-	μs
Series inductance	L_s	-	1.2	-	nH

Forward current $I_F = f(T_A^*; T_S)$

* mounted on alumina




Permissible Pulse Load $R_{thJS} = f(t_p)$




Permissible Pulse Load

$I_{Fmax} / I_{FDC} = f(t_p)$




Diode capacitance $C_T = f(V_R)$

$f = 1\text{MHz}$




Forward resistance $r_f = f(I_F)$

$f = 100\text{MHz}$



Forward current $I_F = f(V_F)$

T_A = parameter



Intermodulation intercept point

$IP_3 = f(I_F)$

f = parameter

